

Interference reduction

- ☐ The signal-to-noise ratio:
 - The amplifier suffers from interference introduced at the input of the amplifier
 - Signal-to-noise ratio: $S/I = V_s/V_n$
- ☐ Enhancement of the signal-to-noise ratio:
 - Precede the original amplifier A_1 by a clean amplifier A_2
 - Use negative feedback to keep the overall gain constant


$$V_{0} = V_{s} \frac{A_{1}A_{2}}{1 + A_{1}A_{2}\beta} + V_{n} \frac{A_{1}}{1 + A_{1}A_{2}\beta} \rightarrow \frac{S}{I} = \frac{V_{s}}{V_{n}}A_{2}$$





Reduction in nonlinear distortion

☐ The amplifier transfer characteristic is linearized through the application of negative feedback



$$\rightarrow \beta = 0.01$$

 \rightarrow A changes from 1000 to 100

$$A_{f1} = \frac{1000}{1 + 1000 \times 0.01} = 90.9$$

$$A_{f2} = \frac{100}{1 + 100 \times 0.01} = 50$$